

Basic principle of electricity and electrical stimulation current



Mohammed Taher Ahmed Ph.D., PT
Associate Professor of Rehabilitation Science
CAMS-KSU



Learning Outcomes

Understand the basic concepts, terminology, and physiology of electrical stimulation and be able to differentiate among them.


Guide the selection of optimal current parameters for effective and safe delivery of electrical stimulation to accomplish therapeutic treatment goals.

Understand adjustment of treatment parameters to meet the needs and responses of individual patients to the application of electrical stimulation to accomplish therapeutic treatment goals

Describe the principles behind the application of electrodes for electrical stimulation to elicit a comfortable level of stimulation and discuss what can be done to improve patient comfort

Be able to create a safe environment when using electrical equipment

Outline



Introduction and History

Electrical Current Parameters

- ❖ Current types
- ❖ Waveforms
- ❖ Time-Dependent Parameters
- ❖ Other Electrical Current Parameters

Effects of Electrical Currents

- ❖ Stimulation of Action Potentials in Nerves/Muscles
- ❖ Wound healing/inflammatory
- ❖ Pain

Indications for the Use of E-Stim

Contraindications and Precautions for the Use of E-Stim

Currents Application Technique

- ❖ Patient Positioning
- ❖ Electrode Type
- ❖ Electrode Placement
- ❖ General Instructions for Electrical Stimulation
- ❖ Documentation



Electrical stimulation

Electrotherapy

- Application of electrical energy for therapeutic purposes

Electrical current is a flow of charged particles

Electrical stimulation

- Application of therapeutic electrical current devices to stimulate excitable tissues, to induce physiological reaction for therapeutic benefits.



Pain management

TENS
(Transcutaneous
Electrical Nerve
Stimulation)



NMES
(Neuromuscular
Electrical
Stimulation)

increasing
muscle strength
or to recover
motor control


ES

FES
(Functional
Electrical
Stimulation)



Facilitate
function
(i.e. walking,
grasping etc.)

EMS
(Electrical Muscle
Stimulation)




retard muscle
atrophy, improve
local blood flow




Electrical Current Parameters

- ❖ Current types
- ❖ Waveforms
- ❖ Time-Dependent Parameters
- ❖ Other Electrical Current Parameters
 - ❖ Current density
 - ❖ Tissue impedance

Current Types



	Direct current (DC)	Alternating Current (AC)	Pulsed current (PC)
Def.	Continuous unidirectional flow of e-'s toward (+) pole	The e- flow in alternating directions in both sides of isoelectric line from (-) and (+) pole.	pulsatile current An interrupted current, whereby the current flows in a series of pulses separated by periods when no current flows. can take on the directionality characteristics of AC or DC current.
Shape	Monophasic	Biphasic	Monophasic or biphasic
Types	"Galvanic current" Interrupted direct current or "interrupted galvanic"	Current can be symmetrical, asymmetrical e.g. TENS,	Groups of pulses are interrupted for short periods of time (inter-pulse intervals) & repeat. Russian current Interferential current
Uses	Iontophoresis Stimulate of denervated muscle;	Pain relief Neuromuscular stimulation.	Pain relief Neuromuscular stimulation Wound healing




Current types



Direct current
(DC)



Alternating
Current (AC)



pulsatile
current



<https://www.youtube.com/watch?v=vN9aR2wKv0U>

1-Alternating vs. Direct Current



Direct current

chemical
reaction

Chemical burn

Alternating current
Pulsed current

No- chemical reaction

Very short pulse duration + Reversing polarity


No Chemical burn



Waveforms


Waveform is a graphic representation of “shape, direction, amplitude, duration and frequency” of the electrical current.

1-Waveforms Shape:





Waveforms Classification





Waveforms Classification


Monophasic

One phase only (+ or -)
Current flows in one direction only.




Biphasic

Two phases (+ and -)
Current flows in both directions.




Polyphasic (pulsatile)

Many phases






Waveforms Classification




Symmetrical, balanced




Asymmetrical, unbalanced



Asymmetrical, balanced





Time-Dependent Parameters

Frequency

Phase
duration
+
Interphase
interval


Pulse
duration
+
Interpulse
interval


Burst
duration
+
Inter-burst
interval



Frequency

The number of pulses per second.
Frequency is measured in Hertz (Hz)





Frequency

High frequency (> 60-120Hz)
Acute pain
Spinal pain modulation

Sensory level

Frequency

motor level

Types of muscles contraction and

< 20Hz	Individual twitch
20-35Hz	Individual twitches become less distinguishable summation
≥35Hz	Tetany muscle contraction

degree of mechanical adaption

fatigue ,

amount of tissue impedance

Lower frequency (≤ 20Hz)
Chronic pain
Supra-spinal pain modulation



Pulse Attributes

Pulse: An individual waveform is referred to a pulse
It contains one, or more phases.
It is measured in microseconds or milliseconds.

Pulse duration (PD)=pulse width: is the time form beginning of first phase of pulse to the end of last phase of a pulse “On Time”

Interpulse interval


is the time between individual pulses “OFF Time”

Phase duration

is a duration of one phase of pulse “on time”

Interphase interval

The time between phases of a pulse “OFF time”



(F) Phase duration.
(G) Pulse duration.



Pulse Attributes

- **Shorter phase durations (150 μ sec)** requires greater intensity (amplitude) to evoke an action potential.
- **Longer phase durations (200 μ sec)** requires less intensity (amplitude) to evoke an action potential.
- **Muscle contraction: Optimum duration – 100-500 μ sec**
- **Stimulation of denervated muscle: Optimum duration > 10msec**



4-Pulse attributes


Burst

A finite series of pulses flowing for a limited time, followed by no current flow.

Burst period = burst interval (BI) + inter-burst interval (IBI).

1-Burst interval (BI)

is the length of the time during which burst occurs.






4-Pulse Charge

Phase charge

is the amount of electrical energy delivered to the tissue with each phase of each pulse which can be measured in micro coulombs per second ($\mu\text{C}/\text{sec}$).

Phase charge relates to:

- Strength of the stimulus or intensity
- The potential for issue damage





Ramp up/ramp down time

Ramp up


The ramp up time is the time it takes for the current amplitude to increase from zero, at the end of the off time, to its maximum amplitude during the on time.
ranged 1-8seconds (2-second)

Plateau

Time during which pulses remain at maximum preset intensity


Ramp down


is the time it takes for the current amplitude to decrease from its maximum amplitude during on time back to zero






Concept check






Concept check



Give the name of each letter and define it, then explain its role in clinical application of electricity for electrotherapy

Concept check



Give the name of each letter and define it, then explain its role in the clinical application of electricity for electrotherapy.



OTHER ELECTRICAL CURRENT PARAMETERS

- **Current amplitude**
- **Current density**
- **Tissue impedance**
 - **Polarity**



Current Amplitude

Intensity (I)=Amplitude

Is the rate of an (e^-) flow through a conductor from cathode (-) to anode (+), per second.

Measured in (mA= 1/1,000 ampere) or


$$1 \text{ amp} = 6.25 \times 10^{18} e^- / \text{sec}$$

Peak current amplitude :

is the maximum (highest) amplitude form zero value of the phase of pulse

Peak to peak amplitude

is the amplitude measured from the peak (maximum) of one phase to the peak (maximum) of next phase only for biphasic current





Current Amplitude

Increase intensity

Increase Strength of stimulation muscles contraction/


Increase Strength of sensory perception

Increase Depth of penetration to deeper tissue (nerve & muscles)

Increase Number of motor unit recruited

Cross-sectional diameter : Large-diameter nerves depolarize first

Location of the nerve: Superficial nerves depolarize first







Current Density (CD)

The amount of current per unit area

**Electrode distance
Determines the Current**




A placed closely electrodes ,
high CD in
superficial tissues.



A spaced apart electrodes.
high CD in
the deeper tissue
(nerve& muscle).

**Electrode Size
Determines the Current Density**





Tissue impedance

- **Ohm's law** showing a comparison of constant current and constant voltage stimulators: $I = V/R$


Volt (V) a unit of force required to move a current of 1 amp in 1 sec against a resistance of 1 Ω (110 V Or 220 v)

Higher voltages (> 150V) ,deeper penetration e.g. HVPC

Resistance (R)

Is a quantitative degree of opposition to the flow of electron.

It is directly proportional to length and inversely proportional to cross section area of a conductor.



I represents the Current
V represents Voltage
R represents Resistance



Tissue impedance

Check the concept


- (a) If you had a 100 V electrical stimulator applied to a muscle that was providing 20,000 Ω resistance, how much current would flow through the muscle?
- (b) What would the current how be if you decreased skin/muscle resistance to 10,000 Ω ?
- Ohm's law tells us there are two ways of increasing current in a circuit. What are they?



Clinical Pearl

Practical tips to decrease skin Resistance

1. Decrease distance between electrodes (length)
2. Increase the size of electrodes (cross section area)
3. **Minimize** air-electrode interface
4. Use electrodes jelly or moisten the electrodes
5. Pre-warming the skin by moisten heat (i.e. hot packs)



Polarity

The charge of an electrode

Positive (anode) or negative (cathode) with a direct or monophasic pulsed current
Constantly changing with an alternating or biphasic pulsed current.

Positive



Negative

Anode

- Lowest Concentration of Electrons
- Connected to the positive terminal
- **Color code is red**
- Attracts (-) Ions
- Acidic Reaction
- Hardening of Tissues
- Decreased Nerve irritability
- Used in later stage of tissue healing to enhance epithelial migration across the wound bed

Cathode

- ❖ Greatest Concentration of Electrons
- ❖ Connected to the negative terminal
- ❖ **Color code is black**
- ❖ Attracts (+) Ions
- ❖ Alkaline Reaction
- ❖ Softening of Tissues
- ❖ Increased Nerve Irritability
- ❖ Used in the early inflammatory stage (3-7days)
- ❖ Used in infected wound
- ❖ **Facilitates Membrane Depolarization**
- ❖ **Usually Considered More Comfortable**



Physiologic Response to electrical stimulation

Effects of Electrical Currents

- ❖ Stimulation of Action Potentials in Nerves/Muscles
- ❖ Wound healing/inflammatory
- ❖ Pain



- Excitation of nerve cells
- Changes in cell membrane permeability
- Protein synthesis
- Stimulation of fibroblast, osteoblast
- Modification of microcirculation

- Skeletal muscle contraction
- Smooth muscle contraction
- Tissue regeneration

- Modification of joint mobility
- Change circulation & lymphatic activity

- Analgesic effects secondary

Physiologic Response to electrical stimulation




Stimulation of Action Potentials In Nerves

Muscle and Nerve Excitation: Concepts to Review

- Resting membrane potential
- Action potential generation and propagation
- Nerve and muscle structure
- Classification of peripheral nerves
- Muscle fiber type and recruitment pattern
- Structure of the motor unit
- Motor unit recruitment


Changing intensity and types of contraction influenced by;

- Frequency
- Intensity
- Pulse duration
- Number of motor unit recruited





Nerve & Muscles Response to E-Stim



Fiber Type	Slow-Twitch (ST)	Fast-Twitch A (FT-A)	Fast-Twitch B (FT-B)
Contraction time	Slow	Fast	Very Fast
Size of motor neuron	Small	Large	Very Large
Resistance to fatigue	High	Intermediate	Low
Activity used for	Aerobic	Long-term Anaerobic	Short-term Anaerobic
Force production	Low	High	Very High
Mitochondrial density	High	High	Low
Capillary density	High	Intermediate	Low
Oxidative capacity	High	High	Low
Glycolytic capacity	Low	High	High
Major storage fuel	Triglycerides	CP, Glycogen	CP, Glycogen



Nerve & Muscles Response to **E-Stim**


1. Facilitate or initiate muscle contraction.
2. Re-educate transplanted muscle contraction.
3. Maintain viability of denervated muscles
4. Increase muscle strength and endurance
5. Retard and prevent disuse atrophy
6. Reduce abnormal muscle tone (e.g. spasticity)
7. Improve postural alignment
8. Maintain and/ or increase range of motion
9. **To improve circulation and lymphatic drainage**
10. **To reduce edema**





Effect of E-Stim on Tissue Repair

1. Increase capillary permeability and blood flow
2. Increase macrophage, leucocytes and activities.
3. Increase fibroblast & osteoblast activity.
4. Induce bactericidal effects.
5. improve circulation and lymphatic drainage
6. Reduce edema





Effect of E-Stim on pain modulation


- Modulation of pain perception through central and peripheral mechanisms

1. Blocking ascending pathways Gate control theory

2. Blocking descending pathway


3. Opiate-mediated pain control

4. Local vasodilatation of blood vessels in ischemic tissues






E-stimulation



Indications



Precautions



Contraindications



E-Stim Indications

- ❖ Modulate acute , chronic and postoperative pain
- ❖ Stimulate contraction o denervated muscles
- ❖ Muscle strength and reeducations
- ❖ Decrease muscles spasm and control spasticity
- ❖ Decreased traumatic edema
- ❖ Wound healing and tissue repair (tendon, ligament,)
- ❖ Diabetic wound , decubitus ulcer, venous and atrial insufficiency ulcer
- ❖ Stimulate nerve regeneration
- ❖ Increase range of motion
- ❖ Increase circulation through pumping action of contracted muscles





E-Stim Contraindications

- ❖ Demand cardiac pacemaker or unstable arrhythmias
- ❖ Over area of venous or arterial thrombosis or thrombophlebitis
- ❖ Over Recent fracture, external fixation
- ❖ Near the operating diathermy devices.
- ❖ Over anterior neck (e.g. carotid sinus, vagus and phrenic nerve).
- ❖ Over bony prominence
- ❖ Over or around Malignancy region
- ❖ Over /around hemorrhage area.
- ❖ Pregnancy—over or around the abdomen





Precautions E-Stim

- ❖ Hypertension patients (monitor blood pressure)
- ❖ Impaired sensation (e.g. Spinal cord injury, neuropathy)
- ❖ Deep internal fixators/open wound
- ❖ Cardiac patients (monitor for signs of dizziness, shortness of breath & syncope)
- ❖ Recent surgery (muscles, tendon, ligament),
- ❖ Allergic reaction to gels, tapes, or electrodes
- ❖ On patients who are unable to provide clear feedback (infant. Old, head injury patients, impaired cognition),





Currents Application Technique

- ❖ Patient Positioning
- ❖ Electrode Type
- ❖ Electrode Placement
- ❖ General Instructions for Electrical Stimulation



Patient Positioning

Patient positioning is dictated by the

Patient comfort and modesty

Area to be treated,

Goal(s) of treatment, and


Device used.



Electrodes

Electrodes are devices attached to the terminals of electrical stimulator through which current enters and leaves the body. Electrodes come in a variety of **sizes, shapes, and materials**, and are named according to their function. The three most popular electrode systems over the years have been

Metal-sponge electrodes



durable , reusable,
inexpensive, inflexible

Carbone electrodes




Relatively inexpensive, fairly
durable, gel or water
required, may cause skin
irritation

Self adhesive electrodes



expensive, less durable,
flexible, skin irritation
Contamination




Electrodes

II-Locations/orientation

1. On/or around the painful area.
2. Over specific **dermatome** corresponding to the painful area.
3. Over specific **myotomes** corresponding to the painful area .
4. Spinal cord segment.
5. Course of peripheral nerve.
6. Motor point.
7. Over trigger point.
8. Acupuncture point.

Muscle fibers are **4 times** more **conductive** when the current flows with the **direction of the fibers** than when it flows **across** them



Electrodes Configuration



Bipolar Configuration


- Equal electrodes size
- Equal Current density under each electrode

Monopolar,

1. **Active electrode (s) [smaller]** is stimulating electrode and placed on the target muscle, greatest current density – treatment effect.
2. **Dispersive electrode [larger]** –required to complete the circuit, low current density – little or no sensation is felt from this electrode

Quadripolar Configuration

- Quadripolar: four electrodes are placed on the target tissue Interferential.



Check the Concept





FIGURE 10.10. A. Preparation of the arm for EMG. B. Preparation of the leg for EMG. C. Preparation of the back for EMG. D. Preparation of the back for EMG.



E-stim Clinical Decision Making





Safety Considerations

Basic Safety : Protection against direct physical hazards when medical electrical equipment is used under normal or other conditions.

Equipment

- Inspection of equipment before use is an important safety measure that should be implemented as routine.

Patients

- Examination and questioned the patient relative to the indications and contraindications of E-stim of the modality being used
- E.g. **Skin Condition and Sensation**