


# **Fits and Tolerances**

Lecture-01 (part-1)



# Why tolerances and fits are required?

Due to the **inevitable inaccuracy of manufacturing methods**, a part cannot be made precisely to a given dimension, the difference between maximum and minimum limits of size of a part is the tolerance.

Tolerance is the total amount that a specific dimension is permitted to vary.

**There is no such thing as an "exact size"**. Tolerance is key to interchangeable parts.

When two parts are to be assembled, the relation resulting from the difference between their sizes before assembly is called a **fit**.

# Examples of Interchangeable Manufacture



**Bottle caps**



**Rims**



**Tires**

# Advantages For Interchangeable Manufacture

**Replacement:** One such part can freely replace another, without any custom fitting (such as filing).

**Easy to Assembly:** This interchangeability allows easy assembly of new devices

**Repairing:** Easier repair of existing devices.

**Minimizing time and cost:** Minimizing both the time and skill required of the person doing the assembly or repair.

# How to decide tolerance?

- Functional requirements of mating parts
- Cost of production
- Available manufacturing process

*Choose as coarse tolerance as possible without compromising functional requirements.*

Proper balance between cost and quality of parts.

# Dimensional Tolerances

Some of the dimensional tolerances terms are defined as follows:

- 1. Dimension** (A dimension is "a numerical value expressed in appropriate units of measure and indicated on a drawing and in other documents along with lines, symbols, and notes to define the size or geometric characteristic, or both, of a part or part feature")
- 2. Size** (It is a number expressed in a particular unit in the measurement of length)
- 3. Basic size** (the theoretical size used as a starting point for the application of tolerances)
- 4. Actual size (of a part)** (the measured size of the finished part after machining)
- 5. Design size** (The ideal size for each component (shaft and hole) based upon a selected fit)

**6. Limits of size** (the maximum and minimum sizes shown by the tolerance dimension)


**7. Maximum limit of size** (Is the maximum size permitted for the part)

**8. Minimum limit of size** (it is the minimum size permitted for the part limit of size)


**9. Maximum material limit (condition)** (is the condition of a part when it contains the most amount of material. The MMC of an external feature (such as a shaft) is the upper limit. The MMC of an internal feature (such as a hole) is the lower limit)

**10. Minimum material limit (condition)** (is the condition of a part when it contains the least amount of material possible. The LMC of an external feature is the lower limit of the part. The LMC of an internal feature is the upper limit of the part.)







Maximum Material Condition




Least Material Condition

- 11. Tolerance** (Tolerance is the difference between maximum limit of size and minimum limit of size)
- 12. Zero line (Basic size)** (it represents the basic size)
- 13. Upper deviation** (It is the algebraic difference between maximum limit of size and its corresponding basic size)
- 14. Lower deviation** (It is the algebraic difference between minimum limit of size and its corresponding basic size)
- 15. Tolerance zone** (a region representing the difference between the upper and the lower limits)
- 16. Unilateral tolerance** (In this method of presenting the limits, variation is allowed only on one side of the zero line)
- 17. Bilateral tolerance** (Here the limits variation is allowed on either sides of the zero line)
- 18. Shaft** (it refers to any external feature of a part, *including any non cylindrical features as well*)
- 19. Hole** (the term used for *any internal feature of a part including any non cylindrical as well*)

## Examples of holes and shafts







**Video link to understand tolerances:**

<https://www.youtube.com/watch?v=KiXHABfRHfQ>


Basic size




$\phi.506$   
 $.498$




**Resulting limit dimensions**



## Unilateral tolerance




## Unilateral Tolerance




Unilateral Tolerance allows variation in only one direction. From basic size.


## Bilateral tolerance



## Bilateral Tolerance




Bilateral Tolerance allow variation in either direction from basic size.




Limits and Tolerance.



**20. Basic shaft** (the shaft chosen as a basis for the shaft basis system of fit)




**21. Basic hole** (the hole chosen as a basis for the hole basis system of fit)




**22. Fit** (Fit is the relationship that exists between two mating parts, a hole and shaft with respect to their dimensional difference )

**23. Basic size of a fit** (common value of the basic size of the two parts of a fit)


# 24. Clearance fit




# 25. Interference fit




# 26. Transition fit




## 27. Minimum clearance




## 28. Maximum clearance



## 29. Minimum interference



## 30. Maximum interference




An **interference fit** results in an interference between two mating parts under all tolerance conditions.

A **clearance fit** results in a clearance between the two mating parts under all tolerance conditions.

A **transition fit** results in either a clearance or an interference condition between two assembled parts.


## 31 - Basic Shaft System of fits

In this system the size of the shaft remains the same and the hole size is varied to get the required fit. **Maximum shaft size is taken as the basic size**, an allowance is assigned, and tolerances are applied on both sides of and away from this allowance.




## 32 - Basic Hole System of fits

In this system the size of the hole remains the same and shaft size is varied to get the required fit. **Minimum hole is taken as the basic size**, an allowance is assigned, and tolerances are applied on both sides of and away from this allowance.




## HOLE AND SHAFT BASIS SYSTEM

### HOLE BASIS SYSTEM



### HOLE BASED SYSTEM

Size of hole is kept constant, shaft size is varied to get different fits.



### SHAFT BASED SYSTEM

Size of shaft is kept constant, hole size is varied to get different fits.

# Some definitions


**Basic Size:** is the size from which limits or deviations are assigned. Basic sizes, usually diameters, should be selected from a table of preferred sizes.

**Deviation:** is the difference between the basic size and the hole or shaft size.

**Upper Deviation:** is the difference between the basic size and the permitted maximum size of the part.


**Lower Deviation:** is the difference between the basic size and the minimum permitted size of the part.





# Some Definitions

**Fundamental Deviation:** is the deviation closest to the basic size. This is identical to the upper deviation for shafts and the lower deviation for holes in a clearance fit.



# Some Definitions

**The hole-basis system** of preferred fits is a system in which the basic diameter is the minimum size of the hole. For the generally preferred hole-basis system, the fundamental deviation is specified by the upper-case letter.

**The shaft-basis system** of preferred fits is a system in which the basic diameter is the maximum size of the shaft. The fundamental deviation is given by the lowercase letter.

## 1.2 Symbols for Tolerances and Deviation and Symbols for Fits:



1. Tolerance values (The tolerance value is a function of the basic size and is indicated by a number called the grade.)

### 2. Tolerance zone position

The position of the tolerance zone with respect to the zero line, is indicated by a letter symbol, **a capital letter for holes and a small letter for shafts.** The tolerance size thus defined by its basic value followed by a symbol composed of a letter and a number. It is established by a combination of the fundamental deviation indicated by a letter and the IT grade number. In the dimension 50H8, the H8 specifies the tolerance zone.

**Example for shaft: 45 g7**

International Tolerance Grade (IT)




## 1.2 Symbols for Tolerances and Deviation and Symbols for Fits:

**3.A fit** (A fit is indicated by the basic size common to both components, followed by symbol corresponding to each component, the hole being quoted first)

**Example: 50 H8 f7**

**Possibly 50 H8 – f7**

**Or 50 H8/f7**



### 1.3: Grades of tolerances:

Eighteen grades of tolerances are provided IT01, IT0 and IT1 to IT16

The Table 1.1 gives the possible degrees of precision or grade of tolerance, achieved with different machine tools.

	For Measuring Tools							For Material										
IT Grades	01	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
								For Fits				For Large Manufacturing Tolerances						

Table 1.1: degree of precision or grade of tolerance

Tolerance grade	Intended for	Applicable to components or machines
IT 01	Gauges	Slip blocks, Reference gauges
IT 0		
IT 1		High quality gauges
IT 2		
IT 3		
IT 4		
<b>IT 5 to IT 11</b>		
IT 5	Fits	Ball bearing
IT 6		Grinding, Honing
IT 7		Broaching
IT 8		Center lathe turning
IT 9		Worn automatic lathe
IT 10		Milling
IT 11		Drilling, Rough turning
<b>IT 12 to IT 16</b>		
IT 12	Not for fits	Light press work
IT 13		Press work
IT 14		Die casting
IT 15		Stamping
IT 16		Sand casting



# International Tolerance Grade Selection

## Representation of Tolerance

2) Number or Grade

IT01, IT0, IT1,....IT16


Tolerance Grade defines range of dimensions  
(dimensional variation)

There are manufacturing constraints on tolerance  
grade chosen


Tolerance grade	Manufacturing process and applications	Machine required
IT01, IT0 IT1 to IT5	Super finishing process, such as lapping, diamond boring etc. Use: Gauges	Super finishing machines
IT6	Grinding	Grinding machines
IT7	Precision turning, broaching, honing	Boring machine, honing machine
IT8	Turning, boring and reaming	Lathes, capstan and automats
IT9	Boring	Boring machines
IT10	Milling, slotting, planing, rolling and extrusion	Milling machine, slotting machine, planing machine and extruders
IT11	Drilling, rough turning	Drilling machine, lathes
IT12, IT13, IT14	Metal forming processes	Presses
IT15	Die casting, stamping	Die casting machine, hammer machine
IT16	Sand casting	—

DIAMETER STEPS IN mm		VALUES OF TOLERANCES IN MICRONS																	
		(1 MICRON = 0.001 mm)																	
		TOLERANCE GRADES																	
		01	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14*	15*	16*
TO and mm	3	0.3	0.5	0.8	1.2	2	3	4	6	8	10	14	25	40	60	100	140	400	600
Over To and mm	3 6	0.4	0.6	1	1.5	2.5	4	5	8	12	18	30	48	75	120	180	300	400	750
Over To and mm	6 10	0.4	0.6	1	1.5	2.5	4	6	9	15	22	36	58	90	150	220	360	580	900
Over To and mm	10 18	0.5	0.8	1.2	2	3	5	8	11	18	27	43	70	110	180	270	430	700	1100
Over To and mm	18 30	0.6	1	1.5	2.5	4	6	9	13	21	33	52	84	130	210	330	520	840	1300
Over To and mm	30 50	0.6	1	1.5	2.5	4	7	11	16	25	39	62	100	160	250	390	620	1000	1600
Over To and mm	50 80	0.8	1.2	2	3	5	8	13	19	30	46	74	120	190	300	460	740	1200	1900
Over To and mm	80 120	1	1.5	2.5	4	6	10	15	22	35	54	87	140	220	350	540	870	1400	2200
Over To and mm	120 180	1.2	2	3.5	5	8	12	18	25	40	63	100	160	250	400	630	1000	1600	2500
Over To and mm	180 250	2	3	4.5	7	10	14	20	29	46	72	115	185	290	460	720	1150	1850	2900
Over To and mm	250 315	2.5	4	6	8	12	16	23	32	52	81	130	210	320	520	810	1300	2100	3200
Over To and mm	315 400	3	5	7	9	13	18	25	36	57	89	140	230	360	570	890	1400	2300	3600
Over To and mm	400 500	4	6	8	10	15	20	27	40	63	97	155	250	400	630	970	1550	2500	4000

# Position of the various tolerance zones for a given diameter in the ISO system



# Position of the various tolerance zones for a given diameter in the ISO system





# Metric Preferred Shaft Based System of fit




Table for fundamental deviations for shafts

Fundamental deviation		Upper deviation es											Lower deviation ei						
		a <sup>a</sup>	b <sup>a</sup>	c	cd	d	e	ef	f	fg	g	h	js <sup>b</sup>	j			k		
Grade		01 to 16											5-6	7	8	4-7	≤3 >7		
Nominal sizes																			
Over	To																		
mm	mm																		
-	3	-270	-140	-60	-34	-20	-14	-10	-6	-4	-2	0	±IT/2	-2	-4	-6	0	0	
3	6	-270	-140	-70	-46	-30	-20	-14	-10	-6	-4	0		-2	-4	-	+1	0	
6	10	-280	-150	-80	-56	-40	-25	-18	-13	-8	-5	0		-2	-5	-	+1	0	
10	14	-290	-150	-95	-	-50	-32	-	-16	-	-6	0		-3	-6	-	+1	0	
14	18	-300	-160	-110	-	-65	-40	-	-20	-	-7	0		-4	-8	-	+2	0	
18	24	-310	-170	-120	-	-80	-50	-	-25	-	-9	0		-6	-10	-	+2	0	
24	30	-320	-180	-130	-	-100	-60	-	-30	-	-10	0		-7	-12	-	+2	0	
30	40	-340	-190	-140	-	-120	-72	-	-36	-	-12	0		-9	-15	-	+3	0	
40	50	-360	-200	-150	-	-145	-85	-	-43	-	-14	0		-11	-18	-	+3	0	
50	65	-380	-220	-170	-	-170	-100	-	-50	-	-15	0		-13	-21	-	+4	0	
65	80	-410	-240	-180	-	-190	-110	-	-56	-	-17	0		-16	-26	-	+4	0	
80	100	-460	-260	-200	-	-210	-125	-	-62	-	-18	0		-18	-28	-	+4	0	
100	120	-480	-280	-210	-	-230	-135	-	-68	-	-20	0		-20	-32	-	+5	0	
120	140	-520	-280	-210	-	-230	-135	-	-68	-	-20	0		-20	-32	-	+5	0	
140	160	-580	-310	-230	-	-230	-135	-	-68	-	-20	0		-20	-32	-	+5	0	
160	180	-660	-340	-240	-	-230	-135	-	-68	-	-20	0		-20	-32	-	+5	0	
180	200	-740	-380	-260	-	-230	-135	-	-68	-	-20	0		-20	-32	-	+5	0	
200	225	-820	-420	-280	-	-230	-135	-	-68	-	-20	0		-20	-32	-	+5	0	
225	250	-920	-480	-300	-	-230	-135	-	-68	-	-20	0		-20	-32	-	+5	0	
250	280	-1050	-540	-330	-	-230	-135	-	-68	-	-20	0		-20	-32	-	+5	0	
280	315	-1200	-600	-360	-	-230	-135	-	-68	-	-20	0	-20	-32	-	+5	0		
315	355	-1350	-680	-400	-	-230	-135	-	-68	-	-20	0	-20	-32	-	+5	0		
355	400	-1500	-760	-440	-	-230	-135	-	-68	-	-20	0	-20	-32	-	+5	0		
400	450	-1650	-840	-480	-	-230	-135	-	-68	-	-20	0	-20	-32	-	+5	0		
450	500	-1650	-840	-480	-	-230	-135	-	-68	-	-20	0	-20	-32	-	+5	0		
Grade		6 to 16																	
500	630	-	-	-	-	-260	-145	-	-76	-	-22	0	±IT/2						0
630	800	-	-	-	-	-290	-160	-	-80	-	-24	0		0					
800	1000	-	-	-	-	-320	-170	-	-86	-	-26	0		0					
1000	1250	-	-	-	-	-350	-195	-	-98	-	-28	0		0					
1250	1600	-	-	-	-	-390	-220	-	-110	-	-30	0		-0					
2000	2500	-	-	-	-	-480	-260	-	-130	-	-34	0		0					
2500	3150	-	-	-	-	-520	-290	-	-145	-	-38	0	0						

\*Not applicable to sizes up to 1 mm.  
<sup>a</sup>In grades 7 to 11, the two symmetrical deviations ± IT/2 should be rounded if the IT value in micrometres is an odd value by replacing it by the even value immediately below.

Adapted from: Metrology & Measurement By Bewoor

[https://books.google.com.sa/books?id=2ck0AwwAAQBAJ&pg=SA6-PA13&ipg=SA6-PA13&dq=fundamental+deviation+selection+fits+IT&source=bl&ots=ZOM0zNqbpP&sig=ofRGWzbxKzJe9uW9zwxVZRZPdk&hl=en&sa=X&redir\\_esc=y#v=onepage&q=fundamental%20deviation%20selection%20fits%20IT&f=false](https://books.google.com.sa/books?id=2ck0AwwAAQBAJ&pg=SA6-PA13&ipg=SA6-PA13&dq=fundamental+deviation+selection+fits+IT&source=bl&ots=ZOM0zNqbpP&sig=ofRGWzbxKzJe9uW9zwxVZRZPdk&hl=en&sa=X&redir_esc=y#v=onepage&q=fundamental%20deviation%20selection%20fits%20IT&f=false)



Table for fundamental deviations for shafts

Fundamental deviation		Lower deviation ei														
Letter		m	n	p	r	s	t	u	v	x	y	z	za	zb	zc	
Grade		01 to 16														
Nominal size																
Over	To															
mm	mm															
-	3	+2	+4	+6	+10	+14	-	+18	-	+20	-	+26	+32	+40	+60	
3	6	+4	+8	+12	+15	+19	-	+23	-	+28	-	+35	+42	+50	+80	
6	10	+6	+10	+15	+19	+23	-	+28	-	+34	-	+42	+52	+67	+97	
10	14	+7	+12	+18	+23	+28	-	+33	-	+40	-	+50	+64	+90	+130	
14	18								+39	+45	-	+60	+77	+108	+150	
18	24	+8	+15	+22	+28	+35	-	+41	+47	+54	+63	+73	+98	+136	+188	
24	30						+41	+48	+55	+64	+75	+88	+118	+160	+218	
30	40	+9	+17	+26	+34	+43	+48	+60	+68	+80	+94	+112	+148	+200	+274	
40	50						+54	+70	+81	+97	+114	+136	+180	+242	+325	
50	65	+11	+20	+32	+41	+53	+66	+87	+102	+122	+144	+172	+226	+300	+405	
65	80				+43	+59	+75	+102	+120	+146	+174	+210	+274	+360	+480	
80	100	+13	-23	+37	+51	+71	+91	+124	+146	+178	+214	+258	+335	+445	+585	
100	120				+54	+79	+104	+144	+172	+210	+254	+310	+400	+525	+690	
120	140	+15	+27	+43	+63	+92	+122	+170	+202	+248	+300	+365	+470	+620	+800	
140	160				+65	+100	+134	+190	+228	+280	+340	+415	+535	+700	+900	
160	180	+17	+31	+50	+68	+108	+146	+210	+252	+310	+380	+465	+600	+780	+1000	
180	200				+77	+122	+166	+236	+284	+350	+425	+520	+670	+880	+1150	
200	225	+20	+34	+56	+80	+130	+180	+258	+310	+385	+470	+575	+740	+960	+1250	
225	250				+84	+140	+196	+284	+340	+425	+520	+640	+820	+1050	+1350	
250	280	+21	+37	+62	+94	+158	+218	+315	+385	+475	+580	+710	+920	+1200	+1550	
280	315				+98	+170	+240	+350	+425	+525	+650	+790	+1000	+1300	+1700	
315	355	+23	+40	+68	+108	+190	+268	+390	+475	+590	+730	+900	+1150	+1500	+1900	
355	400				+144	+208	+294	+435	+530	+660	+820	+1000	+1300	+1650	+2100	
400	450	+26	+44	+78	+126	+232	+330	+490	+595	+740	+920	+1100	+1450	+1850	+2400	
450	500				+132	+252	+360	+540	+660	+820	+1000	+1250	+1600	+2100	+2600	
Grade		6 to 16														
500	560	+30	+50	+88	+150	+280	+400	+600								
560	630				+155	+310	+450	+660								
630	710	+34	+56	+100	+175	+340	+500	+740								
710	800				+185	+380	+560	+840								
800	900	+40	+66	+120	+210	+430	+620	+940								
900	1000				+220	+470	+680	+1050								
1000	1120	+44	+78	+120	+250	+520	+780	+1150								
1120	1250				+260	+580	+840	+1300								

Adapted from: Metrology & Measurement By Bewoor

[https://books.google.com.sa/books?id=2ck0AwAAQBAJ&pg=SA6-PA13&ipg=SA6-PA13&dq=fundamental+deviation+selection+fits+IT&source=bl&ots=ZOM0zNqbpP&sig=ofRGWwezbxKze9uW9zwxVZRZPdk&hl=en&sa=X&redir\\_esc=y#v=onepage&q=fundamental%20deviation%20selection%20fits%20IT&f=false](https://books.google.com.sa/books?id=2ck0AwAAQBAJ&pg=SA6-PA13&ipg=SA6-PA13&dq=fundamental+deviation+selection+fits+IT&source=bl&ots=ZOM0zNqbpP&sig=ofRGWwezbxKze9uW9zwxVZRZPdk&hl=en&sa=X&redir_esc=y#v=onepage&q=fundamental%20deviation%20selection%20fits%20IT&f=false)



Table for fundamental deviations for holes

Fundamental		Lower deviation EI											Upper deviation ES									
Letter	A*	B*	c	CD	D	E	EF	F	FG	G	H	J <sup>b</sup>	J			K		M		N		
Grade	01 to 16											6	7	8	≤R	>R	≤R'	>R'	≤R	>R'		
Nominal sizes																						
Over	To	+	+	+	+	+	+	+	+	+	+											
mm	mm																					
-	3	270	140	60	34	20	14	10	6	4	2	0										
3	6	270	140	70	46	30	20	14	10	6	4	0										
6	10	280	150	80	56	40	25	18	13	8	5	0										
10	14	290	150	95	-	50	32	-	16	-	6	0										
14	18												6	10	15	-1+Δ	-	-7+Δ	-7	-12+Δ	0	
18	24	300	160	110	-	65	40	-	20	-	7	0										
24	30												8	12	20	-2+Δ	-	-8+Δ	-8	-15+Δ	0	
30	40	310	170	120	-	80	50	-	25	-	9	0										
40	50	320	180	130									10	14	24	-2+Δ	-	-9+Δ	-9	-17+Δ	0	
50	60	340	190	140	-	100	60	-	30	-	10	0										
65	80	360	200	150									13	18	28	-2+Δ	-	-11+Δ	-11	-20+Δ	0	
80	100	380	220	170	-	120	72	-	36	-	12	0										
100	120	410	240	180									16	22	34	-3+Δ	-	-13+Δ	-13	-23+Δ	0	
120	140	460	260	200	-	145	85	-	43	-	14	0										
140	160	520	280	210									18	26	41	-3+Δ	-	-15+Δ	-15	-27+Δ	0	
160	180	580	310	230	-	170	100	-	50	-	15	0										
180	200	660	340	240									22	30	47	-4+Δ	-	-17+Δ	-17	-31+Δ	0	
200	225	740	380	260	-	190	110	-	56	-	17	0										
225	250	820	420	280									25	36	55	-4+Δ	-	-20+Δ	-20	-34+Δ	0	
250	280	920	480	300	-	210	125	-	62	-	18	0										
280	315	1050	540	330									29	39	60	-4+Δ	-	-21+Δ	-21	-37+Δ	0	
315	355	1200	600	360	-	230	135	-	68	-	20	0										
335	400	1350	680	400									33	43	66	-5+Δ	-	-23+Δ	-23	-40+Δ	0	
400	450	1500	760	440																		
450	500	1650	840	480																		
Grade	6 to 16																					
500	630	-	-	-	-	260	145	-	76	-	22	0										
630	800	-	-	-	-	290	160	-	80	-	24	0										
800	1000	-	-	-	-	320	170	-	86	-	26	0										
1000	1250	-	-	-	-	350	195	-	98	-	28	0										
1250	1600	-	-	-	-	390	220	-	110	-	30	0										
1600	2000	-	-	-	-	430	240	-	120	-	32	0										

<sup>a</sup>Not applicable to sizes up to 1 mm.  
<sup>b</sup>In grades 7 to 11, the two symmetrical deviations ± IT/2 should be rounded if the IT value in micrometres in an odd value by replacing it by the even value immediately below.  
<sup>c</sup>Special case: for M6, ES = -9 from 250 to 315 (instead of -11).  
<sup>d</sup>Not applicable to sizes up to 1 mm.

Adapted from: Metrology & Measurement By Bewoor

[https://books.google.com.sa/books?id=2ck0AwwAAQBAJ&pg=SA6-PA13&dq=fundamental+deviation+selection+fits+IT&source=bl&ots=ZOM0zNqbpP&sig=ofRGWezbxKzJe9uW9zwxVZRZPdk&hl=en&sa=X&redir\\_esc=y#v=onepage&q=fundamental%20deviation%20selection%20fits%20IT&f=false](https://books.google.com.sa/books?id=2ck0AwwAAQBAJ&pg=SA6-PA13&dq=fundamental+deviation+selection+fits+IT&source=bl&ots=ZOM0zNqbpP&sig=ofRGWezbxKzJe9uW9zwxVZRZPdk&hl=en&sa=X&redir_esc=y#v=onepage&q=fundamental%20deviation%20selection%20fits%20IT&f=false)

Table for fundamental deviations for holes

Please note that all values in this table are actually negative

Fundamental deviation		Upper deviation ES											Values for $\Delta^*$										
Letter	P to ZC	P	R	S	T	U	V	X	Y	Z	ZA	ZB							ZC				
Grade	$\leq 7$	$> 7$																					
Nominal sizes													Grades:										
Over	To	-	-	-	-	-	-	-	-	-	-	-	-	3	4	5	6	7	8				
mm	mm																						
-	3	6	10	14	-	18	-	20	-	26	32	40	60	0	0	0	0	0	0				
3	6	12	15	19	-	23	-	28	-	35	42	50	80	1	1.5	1	3	4	6				
6	10	15	19	23	-	28	-	34	-	42	52	67	97	1	1.5	2	3	6	7				
10	14	18	23	28	-	33	-	40	-	50	64	90	130	1	2	3	3	7	9				
14	18						39	45	-	60	77	108	150										
18	24	22	28	35	-	41	47	54	63	73	98	136	188	1.5	2	3	4	8	12				
24	30						41	48	55	64	75	88	118							160	218		
30	40	26	34	43	-	48	60	68	80	94	112	148	200	1.5	3	4	5	9	14				
40	50						54	70	81	97	114	136	180							242	325		
50	65	32	41	53	66	87	102	122	144	172	226	300	405	2	3	5	6	11	16				
65	80						43	59	75	102	120	146	174							210	274	360	480
80	100	37	51	71	91	124	146	178	214	258	335	445	585	2	4	5	7	13	19				
100	120						54	79	104	144	172	210	254							310	400	525	690
120	140	43	63	92	122	170	202	248	300	365	470	620	800	3	4	6	7	15	23				
140	160						65	100	134	190	228	280	340							415	535	700	900
160	180						68	108	146	210	252	310	380							465	600	780	1000
180	200	50	77	122	166	266	284	350	425	520	670	880	1150	3	4	6	9	17	26				
200	225						80	130	180	258	310	385	470							575	740	960	1250
225	250						84	140	196	284	340	425	520							640	820	1050	1350
250	280	56	94	158	218	315	385	475	580	710	920	1200	1550	4	4	7	9	20	29				
280	315						98	170	240	350	425	525	650							790	1000	1300	1700
315	355	62	108	190	268	390	475	590	730	900	1150	1500	1800	4	5	7	11	21	32				
355	400						114	208	294	435	530	660	820							1000	1300	1650	2100
400	450	68	126	232	330	490	595	740	920	1100	1450	1850	2400	5	5	7	13	23	34				
450	500						132	252	360	540	660	820	1000							1250	1600	2100	2600
Grade		6 to 16																					
500	560	78	150	280	400	600																	
560	630		155	310	450	660																	
630	710	88	175	340	500	740																	
710	800		185	380	560	840																	
800	900	100	210	430	620	940																	
900	1000		220	470	680	1050																	
1000	1120	120	250	520	780	1150																	
1120	1250		260	580	840	1300																	

\* In determining K, M, N up to Grade 8 and P to ZC up to Grade 7, add the  $\Delta$  value appropriate to the grade as indicated, e.g. for P7 from 18 to 30,  $\Delta = 8$  therefore ES = -14.

Adapted from: Metrology & Measurement By Bewoor

[https://books.google.com.sa/books?id=2ck0AwAAQBAJ&pg=SA6-PA13&dq=fundamental+deviation+selection+fits+IT&source=bl&ots=ZOM0zNqbpP&sig=ofRGWezbKzJe9uW9zwxVZRZPdk&hl=en&sa=X&redir\\_esc=y#v=onepage&q=fundamental%20deviation%20selection%20fits%20IT&f=false](https://books.google.com.sa/books?id=2ck0AwAAQBAJ&pg=SA6-PA13&dq=fundamental+deviation+selection+fits+IT&source=bl&ots=ZOM0zNqbpP&sig=ofRGWezbKzJe9uW9zwxVZRZPdk&hl=en&sa=X&redir_esc=y#v=onepage&q=fundamental%20deviation%20selection%20fits%20IT&f=false)



# Example

## Creating a Clearance Fit using The Basic Hole System

Given the following fit  $\Phi 40 - H11/c11$

From table for hole diameter = 40 and H11 we find

Upper deviation =  $+160 \mu\text{m}$  & Lower deviation =  $0$

From table for shaft diameter = 40 and c11 we find

Upper deviation =  $-120 \mu\text{m}$  & Lower deviation =  $-280 \mu\text{m}$


Calculations of dimension limits for hole and shaft

- Maximum hole diameter =  $40 + 0.16 = 40.16 \text{ mm}$
- Minimum hole diameter =  $40 + 0 = 40 \text{ mm}$
- Maximum shaft diameter =  $40 + (-120) = 39.88 \text{ mm}$
- Minimum shaft diameter =  $40 + (-280) = 39.72 \text{ mm}$

Maximum clearance = Maximum hole diameter – Minimum shaft diameter  
 $= 40.16 - 39.72 = 0.44 \text{ mm}$

Minimum clearance = Minimum hole diameter – Maximum shaft diameter  
 $= 40 - 39.88 = 0.12 \text{ mm}$

Allowances = minimum clearance =  $0.12 \text{ mm} = 120 \mu\text{m}$



# Problems for fits and tolerances

**Problem 1:** For a given fit of 50 H7/g8, answer the following questions:

- Which fit system it represents?
- Draw sketches to show the fit.
- calculate the shaft and hole dimensions.
- What are the values of the maximum and minimum clearances, and maximum and minimum interferences?

# Problems for fits and tolerances

**Problem 2:** For a given fit of 45 G7/h6, answer the following questions:

- Which fit system it represents?
- Draw sketches to show the fit.
- Calculate the shaft and hole dimensions.
- What are the values of the maximum and minimum clearances, and maximum and minimum interferences?

# Problems for fits and tolerances

**Problem 3:** For a given fit of 30 H6/p7, answer the following questions:

- Which fit system it represents?
- Draw sketches to show the fit.
- Calculate the shaft and hole dimensions.
- What are the values of the maximum and minimum clearances, and maximum and minimum interferences?

# Problems for fits and tolerances

**Problem 4:** For a given fit of 50 H8/f7, answer the following questions:

- Which fit system it represents?
- Draw sketches to show the fit.
- Calculate the shaft and hole dimensions.
- What are the values of the maximum and minimum clearances, and maximum and minimum interferences?



# Problems for fits and tolerances

**Problem 5:** For a given fit of 50 F7/h8, answer the following questions:

- Which fit system it represents?
- Draw sketches to show the fit.
- Calculate the shaft and hole dimensions.
- What are the values of the maximum and minimum clearances, and maximum and minimum interferences?